


**PLEASE FOLLOW THESE INSTRUCTIONS TO  
UPDATE THE POSTAGE RATES IN YOUR SCALE**

**Model: DI3kg/DI 3kg i/f**




**STEP 1**

Turn the power 'OFF' at the wall socket  
Failure to not switch off may damage your scales




**STEP 2**

Turn keyboard over and remove the old rate chip



**STEP 3**

Take the new chip out of the packaging



**STEP 4**

Insert the new chip with the yellow dot facing the adjacent yellow marking on the keyboard, press in firmly



**STEP 5**

Turn the keyboard back over then turn the power back 'ON'

**IF ANY OF THE ABOVE STEPS FAIL, PLEASE START AGAIN FROM STEP 1. IF YOU ARE STILL HAVING DIFFICULTIES, PLEASE VISIT OUR WEBSITE [www.fpmailing.co.uk](http://www.fpmailing.co.uk)**