



**PLEASE FOLLOW THESE INSTRUCTIONS TO
UPDATE THE POSTAGE RATES IN YOUR SCALE**

Model: DI5kg



STEP 1

Turn the power 'OFF' at the wall socket
Failure to not switch off may damage your
scales



STEP 2

Turn keyboard over and remove the old
rate chip



STEP 3

Take the new chip out of the packaging



STEP 4

Insert the new chip with the yellow dot
facing the adjacent yellow marking on the
keyboard, press in firmly



STEP 5

Turn the keyboard back over then turn the
power back 'ON'

**IF ANY OF THE ABOVE STEPS FAIL, PLEASE START AGAIN FROM STEP 1. IF YOU
ARE STILL HAVING DIFFICULTIES, PLEASE VISIT OUR WEBSITE www.fpmailing.co.uk**