

ultimail Teleset Re-Crediting Instructions



Overview

Teleset re-crediting is the loading of postage from your FP Teleset account onto your franking machine. This involves the machine dialling up to the FP Teleset server via your analogue telephone line. The franking machine then requests the amount you have specified and transfers the funds securely to your ultimail franking machine.

Re-crediting requirements

As mentioned above, you require an analogue telephone line.

You must have funds available on your FP Teleset account ready for downloading.

You must download your postage funds in £10 increments. i.e. £10, £20, £50, £100.

(Re-crediting of £56 for example is not possible)


The minimum amount for download is £10.

The maximum amount for download is £9990.

SELECT TELESET	
<input checked="" type="radio"/> TELESET MODEM	<input type="radio"/>
<input type="radio"/>	<input type="radio"/>
<input type="radio"/> SET UP MODEM CONFIGURATION	<input type="radio"/>
<input type="radio"/> BOOKING REPORT FOR LAST LOAD PROCEDURE	<input type="radio"/>
Please select a function.	

LOAD TELESET	
<input type="radio"/>	<input type="radio"/>
<input type="radio"/>	<input type="radio"/>
<input type="radio"/>	<input type="radio"/>
<input type="radio"/>	<input type="radio"/>
TELESET (remote setting) successfully completed. New R1 register value (DESCENDING): £ 1,150.16	<input type="radio"/>
<input type="radio"/>	<input checked="" type="radio"/> CONTINUE
Press CONTINUE to close the procedure.	

Loading postage

- Open the TELESET menu with the  key.
 - Select TELESET MODEM Or RUN TELESET
To start the TELESET procedure
- Now simply follow the instructions in the display.
- Maintain the indicated loading amount or overwrite with a new amount. Acknowledge with CONTINUE.

After a security prompt the ultimail establishes a connection with the TELESET data centre. Messages in the display will inform you about the status (connection establishment, data transfer...).

At the end of the remote setting, the ultimail will show the new descending.

- Press CONTINUE to end the TELESET process.

Are you sure you want to perform Teleset? Yes or No

Once "Yes" has been selected the machine will now state connecting

You may need to push "continue" within 30 seconds to confirm the reset